

ELLE エレガントトルソー




ELE 1 本体高さ 94.0 B82.0 W58.0 H86.0
右腕 ELE 1 / 右手先 PW H
左腕 ELE 1 / 左手先 PW A



ELE 2 本体高さ 92.0 B82.0 W58.0 H86.0
右腕 ELE 2 / 右手先 PW G
左腕 ELE 2 / 左手先 PW B



ELE 3 本体高さ 106.0 B81.0 W58.0 H90.0
右腕 ELE 3 / 右手先 PW A
左腕 ELE 3 / 左手先 PW A



ELE 4 本体高さ 101.0 B82.0 W57.5 H87.0
右腕 ELE 4 / 右手先 PW D
左腕 ELE 4 / 左手先 PW A



ELE 5 本体高さ 103.0 B81.0 W58.0 H89.0
右腕 ELE 5 / 右手先 PW D
左腕 ELE 5 / 左手先 PW A



ELE 6 本体高さ 103.0 B84.0 W61.0 H99.0
右腕 ELE 6 / 右手先 PW A
左腕 ELE 6 / 左手先 PW A



ELE 7V 本体高さ 92.5 B81.0 W60.5 H89.5
右腕 ELE 7 / 右手先 PW 16
左腕 ELE 7 / 左手先 PW E




ELE 8V 本体高さ 94.0 B79.0 W58.5 H90.0
右腕 ELE 8 / 右手先 PW C
左腕 ELE 8 / 左手先 PW F



ELE 9V 本体高さ 91.0 B76.0 W57.5 H83.0
右腕 ELE 9 / 右手先 PW A
左腕 ELE 9 / 左手先 PW E



ELE 10V 本体高さ 92.5 B77.0 W56.0 H83.0
右腕 ELE 10 / 右手先 PW H
左腕 ELE 10 / 左手先 PW C



ELE 11 本体高さ 108.0 B94.0 W81.0 H92.0
右腕 ELE 11 / 右手先 PM M
左腕 ELE 11 / 左手先 PM J



ELE 12 本体高さ 108.0 B92.5 W82.0 H92.5
右腕 ELE 12 / 右手先 PM M
左腕 ELE 12 / 左手先 PM K