





LSW/LSM

エルエスダブル / エルエスエム heel Ladies 2cm Men's 2cm footsize Ladies 23.5cm Men's 26.0cm



69.0cm



90.0cm



117.0cm

LSW-1
高さ 175 / B80 / W58 / H81
腕 RLSW-1 LLSW-1 / 手先 RSA-38 LSA-32 / 肩幅 38

LSW-2
高さ 178 / B78 / W58 / H84
腕 RLSW-2 LLSW-2 / 手先 RSA-30 LSA-28 / 肩幅 39

LSW-3(B)
高さ 151 / B78 / W59 / H83
腕 RLSW-3B LLSW-3B / 手先 RSA-23 LSA-26 / 肩幅 39




117.0cm



LSW-4
高さ 177 / B80 / W57 / H82
腕 RLSW-4 LLSW-4 / 手先 RSA-29 LSA-21 / 肩幅 39

Waist Stand

LSW-1,2,4,LSM-1,2は
ウエストスタンドベースの
使用が可能です。



ベース LSW-1,2,4,LSM-2 Aタイプ
(B-10+S-73)
ベース LSM-1 Bタイプ
(B-11+S-74)

LSW-3(A)
高さ 151 / B78 / W59 / H83
腕 RLSW-3A LLSW-3A / 手先 RSA-38 LSA-32 / 肩幅 39




LSW-5
高さ 148 / B83 / W51 / H88
腕 RLSW-5 LLSW-5 / 手先 RSA-21 LSA-19 / 肩幅 39 / 台の高さ 42




110.0cm



LSW-6(B)
高さ 88 / B80 / W58
腕 RLSW6B LLSW6B / 手先 RSA32 LSA31 / 肩幅 39





LSW-6(A)
高さ 88 / B80 / W58
腕 RLSW6A LLSW6A / 手先 RSA38 LSA32 / 肩幅 39



LSM-1
高さ 183 / B98 / W70 / H87
腕 RLSM-1 LLSM-1 / 手先 RM-1 LM-2 / 肩幅 43



120.0cm



LSM-2
高さ 186 / B98 / W70 / H87
胸 RLSM-2 LLSM-2 / 手先 RM-1 LM-2 / 肩幅 44

Head

LSW、LSMはヘッドホン、サングラスの装着が可能です。



ヘッドホン装着例





サングラス装着例

LSW/LSM



LSW-7
T:171.0 / B:80.0 / W:62.5 / H:83.0
Shoulders:42 / Heel:2.5 / Foot:23.5
Arm:RLSW7 LLSW7 / Hand:RWG LWD



LSM-3
T:178.0 / B:86.0 / W:68.5 / H:87.0
Shoulders:44 / Heel:2.0 / Foot:25.5
Arm:RLSM3 LLSM3 / Hand:RMM LMK